


HEL2995 - 7" Colour Reversing Camera Kit With AI Person Detection Function.

Instructions.

WIRING DIAGRAM



CHANNELS

CH1 - Front Camera

CH2 - Back Camera

CH3 - Left Camera (AI Detection)

CH4 - Right Camera (AI Detection)

WIRE COLOURS

Black - Ground/Earth

Red - Live (12-36v DC)

Yellow - Ignition/Switch

Green - CH2 Trigger Wire (**unlikely to be required for off-Highway machinery**)

Blue - CH3 Trigger Wire (**unlikely to be required for off-Highway machinery**)

Grey - CH4 Trigger Wire (**unlikely to be required for off-Highway machinery**)

WIRING INSTRUCTIONS:


DISCLAIMER: *The following is a rough guide – please consult auto-electrician before proceeding. HTS Spares Ltd are **NOT** responsible for any electrical work carried out.*

For basic functionality:

- **OPTION 1** - Connect 'live' (red) to positive/permanent live, connect 'ground' (black) to negative/earth, connect 'switch/ignition' (yellow) to ignition.
- **OPTION 2** - Twist 'live' (red) and 'switch' (yellow) together and connect to positive/permanent live, connect 'ground' (black) to negative/earth.

BUTTON KEY

DECREASE




MENU



INCREASE



AV, UP/DOWN



POWER LIGHT



BASIC OPERATION

- Screen powers on automatically with ignition
- To make any system changes, select 'MENU'
- Press 'AV' to scroll through any menu/screen
- Press 'MENU' to select sub-menus
- Press and hold 'MENU' to save settings and to return to previous screen

MAIN MENU SETTINGS

Press **MENU** to enter Settings Screen.

VIEW FILES




- Press **MENU** to enter 'View Files'




- Press **AV** to scroll through menu and use **+** and **-** to adjust values. Press and hold **MENU** for 2-3 seconds to save and return to Settings screen.

SYSTEM SETTINGS

- Press **AV** to scroll to System Settings




- Press **MENU** to enter




- Press **AV** to scroll through menu.
- **Volume Setting** and **Screen Sleep** - use **+** and **-** to adjust.

TIME & DATE




- Press **MENU** to enter. Press **+** and **-** to adjust values. Press **MENU** to move to next value. When finished, press **MENU** to move to 'Yes'. Press and hold **MENU** to save and return to System Settings screen.

DISPLAY



- Press **MENU** to enter. Press **AV** to scroll. Press **+** and **-** to adjust values. Press and hold **MENU** to save and return to System Settings screen.

CDR SETTINGS




- Press **MENU** to enter. Press **AV** to scroll. Press **+** and **-** to adjust values. Press and hold **MENU** to save and return to System Settings screen.


SMART DRIVE



- Press **MENU** to enter. Press **MENU** to calibrate, this proceeds to the following screen. ↓



- Press **AV** to select camera.



- In this screen you can change the size of the detection square one corner at a time – you can only change the shape where the red dot is.
- Press **AV** until the square in the middle of the four arrows is selected. Press **MENU** to move the red dot to the desired corner. Press **AV** to select one of the four arrows for the direction required. Press **MENU** to move the shape. Once the shape of the detection area is confirmed, press **AV** to move to '**SAVE**'. Press and hold **MENU** for 2-3 seconds to save and return to previous screen.

SMART DRIVE SETTINGS



- In the Smart Drive screen press the **AV** button to scroll through parameter settings and press the **MENU** button to turn on or off as required. These parameters are 'on' as a factory setting.

ABOUT DEVICE



- Press **MENU** to enter. This tells you the camera's current software version.